



STAR LOA 5

En AWY W-202, T-103, cruzar R035 FAG VOR/DME FL130 o superior, cruzar R020 FAG VOR/DME FL80 o superior, posterior directo a PADEM INT 4500FT o superior, luego según autorización ATC.

On AWY W-202, T-103, cross R035 FAG VOR/DME at or above FL120, cross R020 FAG VOR/DME at or above FL80, then direct to PADEM INT at or above 4500FT, then according to ATC clearance.