



<b>IQUIQUE</b>	
RDR	128.3
<b>ATACAMA</b>	
APP	120.3
TWR	118.3

Nivel de Transición by ATC  
 Transition Level by ATC

No se ajusta a escala / Not to scale

**STAR NENAT 2B**

**NENAT 2B:** En AWY U/Q-803 cruzando NENAT, o en AWY UV-204 cruzando D77 DAT, abandonar AWY para interceptar R020 (TR200°) DAT VOR/DME, cruzar KESAD a FL170 o superior, D40 N DAT FL110 o superior. En D28 N DAT viraje derecha para orbitar D25 N DAT. Cruzar R008 FL80 o superior, viraje izquierda para interceptar R356 (TR176°). Cruzar D21 N DAT FL55 o superior, continuar descenso a 3500FT o superior hasta DERIL / ANNIX, luego según autorización ATC.

**NENAT 2B:** On AWY U/Q-803 crossing NENAT, or on AWY UV-204 crossing D77 DAT, leave AWY to intercept R020 (TR200°) DAT VOR/DME, cross KESAD at or above FL170, cross D40 N DAT at or above FL110. On D28 N DAT turn right to join D25 N DAT. Cross R008 at or above FL80, left turn to intercept R356 (TR176°). Cross D21 N DAT at or above FL55, then continue descent to 3500 FT or above until DERIL / ANNIX, then according to ATC clearance.

DASA / SECCION AIS-MAP