



Notas
 1.- Requiere aprobación RNAV1 o RNP1.
 2.-Requiere GNSS.

Notes
 1.- RNAV1 OR RNP1 approval RQRD.
 2.- GNSS required.

Nivel de Transición by ATC
 Transition Level by ATC

No se ajusta a escala / Not to scale

STAR OPURA 1D/ARGOS 1D/PARET 1C RNAV

OPURA 1D: Desde OPURA directo a LAPOL directo a BA220 - NEBAL. Cruzar OPURA FL100 o superior, LAPOL FL100 o superior, BA220 7000FT o superior, NEBAL 6000FT o superior, luego según autorización ATC.

OPURA 1D: From OPURA direct to LAPOL direct to BA220 - NEBAL. Cross OPURA at or above FL100, LAPOL at or above FL100, BA220 at or above 7000FT, NEBAL at or above 6000FT, then according to ATC clearance.

ARGOS 1D: Desde ARGOS directo a LAPOL directo a BA220 - NEBAL. Cruzar ARGOS FL110 o superior, LAPOL FL100 o superior, BA220 7000FT o superior, NEBAL 6000FT o superior, luego según autorización ATC.

ARGOS 1D: From ARGOS direct to LAPOL direct to BA220 - NEBAL. Cross ARGOS at or above FL110, LAPOL at or above FL100, BA220 at or above 7000FT, NEBAL at or above 6000FT, then according to ATC clearance.

PARET 1C: Desde PARET directo BA304 - BA237 - SUPAM. Cruzar PARET FL170 o superior, BA304 FL100 o superior, BA237 FL80 (u 8000FT) o superior, SUPAM 6000FT o superior, luego según autorización ATC.

PARET 1C: From PARET direct to BA304 - BA237 - SUPAM. Cross PARET at or above FL170, BA304 at or above FL100, BA237 at or above FL80 (or 8000FT), SUPAM at or above 6000FT, then according to ATC clearance.